

INSTALLER MANUAL

Pellet Stove








©2019 CADEL srl | All rights reserved - Tutti i diritti riservati

**KRISS³ - TECNO³ - EVO³ - ELISE³ - SHELL³ - CRISTAL³
GLASS - VERVE AIRTIGHT - PRETTY AIRTIGHT - BREEZE AIRTIGHT
TITANIA AIRTIGHT - VENERE AIRTIGHT**

SUMMARY

1	MANUAL SIMBOLOGY.....	2
2	PACKAGING AND HANDLING.....	2
2.1	PACKAGING	2
2.2	REMOVING THE STOVE FROM THE PALLET	2
2.3	STOVE HANDLING.....	3
3	CHIMNEY FLUE	3
3.1	INTRODUCTION	3
3.2	CHIMNEY FLUE	3
3.3	TECHNICAL FEATURES.....	4
3.4	HEIGHT-DEPRESSION.....	5
3.5	MAINTENANCE.....	5
3.6	CHIMNEY POT.....	5
3.7	CHIMNEY COMPONENTS	6
3.8	CHIMNEY FLUE CONNECTION.....	6
3.9	EXAMPLES OF CORRECT INSTALLATION.....	7
4	COMBUSTION AIR.....	9
4.1	EXTERNAL AIR INLET.....	9
4.2	COMBUSTIBLE AIR INLET FOR SEALED-CHAMBER INSTALLATION	10
4.3	COMBUSTIBLE AIR INLET FOR SEALED-CHAMBER INSTALLATION (KRIS ³ - TECNO ³ - EVO ³ - ELISE ³ - SHELL ³ - SHELL ³ PS - CRISTAL ³ - GLASS - VERVE AT - PRETTY AT - TITANIA AT - VENERE AT)	10
4.4	COMBUSTIBLE AIR INLET FOR SEALED-CHAMBER INSTALLATION (SHELL ³ UP - BREEZE AT)	11
5	INSTALLATION.....	11
5.1	INTRODUCTION	11
5.2	OVERALL DIMENSIONS	12
5.3	GENERAL INSTALLATION	20
5.4	STOVE DOOR REMOVAL/INSTALLATION	21
5.5	EVO ³ SIDE PANELS ASSEMBLY	21
5.6	MOUNTING THE VERVE AIRTIGHT SIDE PANELS....	22
5.7	MOUNTING THE GLASS DOOR	23
5.8	MOUNTING THE PRETTY AIRTIGHT SIDE PANELS..	24
5.9	TECNA ³ SIDE PANEL DISASSEMBLY	25
5.10	KRIS ³ - CRISTAL ³ SIDE PANEL DISASSEMBLY	26
5.11	ELISE ³ /SHELL ³ SIDE PANEL DISASSEMBLY	26
5.12	VERVE AIRTIGHT SIDE PANEL DISASSEMBLY	27
5.13	SHELL ³ /SHELL ³ PS /SHELL ³ UP COATING REMOVAL	27
5.14	GLASS SIDE PANEL DISASSEMBLY	28
5.15	BREEZE AIRTIGHT SIDE PANEL DISASSEMBLY	29
5.16	ELECTRIC CONNECTION	29
5.17	CONNECTION TO THE EXTERNAL THERMOSTAT	30
5.18	STOVE CALIBRATION AND DEPRESSION MEASUREMENT	30
6	SPECIAL MAINTENANCE	31
6.1	INTRODUCTION	31
6.2	FEED SCREW MAINTENANCE.....	31
6.3	FUME CONDUIT CLEANING.....	32
6.4	FUME CHAMBER AND FUME PASSAGES CLEANING...	33
6.5	LOWER COMPARTMENT CLEANING	34
6.6	FUME PIPES ANNUAL CLEANING	34
6.7	GASKET REPLACEMENT.....	35
7	IN CASE OF ANOMALY.....	35
7.1	PROBLEM SOLVING	35
8	TECHNICAL DATAS	38
8.1	FUSE REPLACEMENT	38
8.2	FEATURES.....	39

1 MANUAL SIMBOLOGY

	USER
	AUTHORISED TECHNICIAN (ONLY to interpret or the Stove-manufacturer or the Authorized Technician of Technical Assistance Service approved by the Stove-manufacturer)
	SPECIALIZED STOVE-REPAIRER
	CAUTION: READ CAREFULLY THE NOTE
	CAUTION: DANGER OR IRREVERSIBLE DAMAGE POSSIBILITY

- The icons with the stylized figures indicates whom the subject dealt in the paragraph is addressed to (between the User and/or the Authorized Technician and/or the Specialized Stove-repairer).
- WARNING symbols indicates an important note.

2 PACKAGING AND HANDLING

2.1 PACKAGING

- The packaging is made up of recyclable cardboard boxes according to RESY standards, recyclable expanded polystyrene inserts and wooden pallets.
- All packaging materials can be re-used for a similar use or eventually discharged as waste assimilable to the municipal solid ones, in accordance with current regulations.
- After having removed the packaging please assure you about the integrity of the product.

2.2 REMOVING THE STOVE FROM THE PALLET

Proceed as follows:




Fig. 1 - Bracket removal

- Remove the brackets which secure the feet of the stove (see **Fig. 1**). Then remove the stove from the pallet.

2.3 STOVE HANDLING

Both whether the stove is packed or not it is necessary to observe the following instructions for handling and transporting the stove from its sale point to its installation point and for any future movements:

- The stove must be handled with idoneous means paying attention to the existing safety regulations;
- do not turn the stove upside down and/or upset it on one side, but keep it in vertical position or as accorded with the constructor instructions;
- if the stove is made up of ceramic, stone, glass or any particularly fragile material components, all must be moved with the utmost care.

3 CHIMNEY FLUE



3.1 INTRODUCTION

This chapter about the Chimney Flue has been drawn up in cooperation with Assocosma (www.assocosma.org) and is based on European Standards (EN 15287 - EN 13384 - EN 1856 - EN 1443) and UNI 10683:2012.

It provides instructions for a good and correct execution of the chimney flue but it does not absolutely replace the current standards which the qualified manufacturer/installer should comply with.

3.2 CHIMNEY FLUE




Fig. 2 - Chimney Flues

LEGEND	Fig. 2
1	Chimney flue with insulated stainless-steel pipes
2	Chimney flue on the existing chimney
3	Inspection plug
4	Inspection door
5	$\geq 3,5 \text{ mt}$

- The chimney flue or chimney is of great importance for the correct running of the heating appliance.
- It is fundamental that the chimney flue is perfectly built and always maintained with a perfect efficiency.
- The chimney flue must be sole (see **Fig. 2**) with insulated stainless-steel pipes (1) or installed on the existing chimney flue (2).
- Both this solutions must be endowed with an inspection plug (3) and/or an inspection door (4).

3.3 TECHNICAL FEATURES




Fig. 3 - Inclined roof

LEGEND	Fig. 3
1	Height over the ridge of the roof = 0,5 mt
2	Roof inclination $\geq 10^\circ$
3	90°
4	Measured distance at 90° from the roof surface = 1,3 mt

- The chimney flue must be sealed from fumes.
- It must have a vertical run without narrowing. It must be realized with fume and condensation resistant materials with thermal insulation and able to last against usual mechanical stresses.



It must be insulated to avoid condensation and to reduce fume cooling effects.

- The stove must be spaced out from fuels or flammable materials with an air gap or with insulating materials. Check the distance with the chimney manufacturer.
- The chimney entrance must be placed in the same room where the appliance is installed or otherwise in the adjacent room and it must be provided with a solid and condensation collection chamber under the entrance, accessible through the sealed metal gate.
- Auxiliary exhaust fans cannot be installed neither along the chimney nor on the chimney pot.
- The inner section of the chimney flue can be round (the best one) or square and the jointed sides must have a minimum radius of 20 mm.
- The section dimension must be:
 - **minimun Ø100 mm**
 - **recommended max Ø180 mm**
- Made the efficiency of the chimney flue overhauled by an expert stove-repairer and if necessary cover the chimney flue with materials in compliance with current regulations.
- The flue system must be placed on the roof.
- The chimney flue must be provided CE in accordance with EN 1443 regulation. Please find attached an example of label:



Fig. 4 - Example of label

3.4 HEIGHT-DEPRESSION

The depression (draught) of a chimney flue depends also on its height. Check the depression with the values provided at **FEATURES a pag. 40**. Minimum height 3,5 meters.

3.5 MAINTENANCE

- The fumes extraction pipes (fumes conduit + chimney flue + chimney pot) must always be cleaned, scrubbed and checked by an expert stove-repairer, in compliance with current regulations, with the instructions of the stove-manufacturer and the directives of your insurance company.
- In case of doubts, please follow the most restrictive regulations.
- Have your chimney flue and chimney pot checked and cleaned by an expert chimney sweep at least once a week. The chimney sweep has to release a written declaration about the security of the system.
- Not cleaning compromise safety.

3.6 CHIMNEY POT




Fig. 5 - Anti-wind chimney pots

The chimney pot is important for the correct running of the heating appliance:

- We recommend using an anti-wind chimney pot, see **Fig. 5**.
- The hole width for fumes exhaust must be the double of the chimney flue width and fitted in a way that the fume exhaust is assured also in case of wind.
- It should prevent the infiltration of rain, snow and animals.
- The outlet height in the atmosphere must be away from the reflux area caused by the roof structure or by obstacles laying nearby (see **Fig. 3**).

3.7 CHIMNEY COMPONENTS




Fig. 6 - Chimney components

LEGEND	Fig. 6
1	Chimney pot
2	Fume outlet
3	Chimney flue
4	Thermal insulation
5	External wall
6	Chimney union
7	Fume pipe
8	Heat generator
9	Inspection door
10	T-union with inspection plug

3.8 CHIMNEY FLUE CONNECTION

Your pellet stove works through a fume draught forced by a fan. It is obligatory to check that all pipes are realized in compliance with the following regulation on material selection: EN 1856-1, EN 1856-2 e UNI/TS 11278. All must be effected by specialized personnel or companies as provided by UNI 10683:2012.

- The connection between the appliance and the chimney flue should be short in order to favor the draught and to avoid condensation in the pipes.
- The fume conduit should be equivalent or longer than the outlet joint ones (Ø 80 mm).
- Some stove models are endowed with a lateral and/or back exhaust. Check that the unused exhaust is sealed with the plug given with standard equipment.

SYSTEM TYPE	Ø80 mm PIPE	Ø100 mm PIPE
Minimum vertical length	1,5 mt	2 mt
Maximum length (with 1 union)	6,5 mt	10 mt
Maximum length (with 3 unions)	4,5 mt	8 mt
Maximum number of unions	3	3
Level section (minimum inclination 3%)	2 mt	2 mt
Installation at a height above 1200 m a.s.l.	NO	Obligatory

- Use a plate pipe for stoves of Ø80 mm or Ø100 mm depending on the type of system and with silicone gaskets.
- It is forbidden to use metal, fibre cement or aluminium flexible pipes.
- For change of direction it is obligatory always to use a union (with angle > 90°) with inspection plug which enables an easy periodic cleaning of the pipes.
- Please assure you that after the cleaning the inspection plugs are sealed with its efficient gasket.
- It is forbidden to exhaust flue gases directly from the wall towards the outside and closed spaces also at open top.
- The fume conduit must be placed at a distance of minimum 500 mm from flammable or heat-susceptible components.
- It is prohibited to connect more than one wood/pellet (*) or any other type of appliance (vent cowl...) to the same flue.

(*) unless there are national derogations (for instance in Germany), which under suitable conditions allow for the installation of several appliances in the same fireplace. In any case, strictly follow the product/installation requirements of the relative regulations/legislation in force in that country.

3.9 EXAMPLES OF CORRECT INSTALLATION




Fig. 7 - Example 1

LEGEND	Fig. 7
1	Insulating material
2	Reduction from Ø100 to Ø80 mm
3	Inspection plug
4	Minimum safety distance = 0,5 mt

- Chimney flue installation Ø100/120 mm with an enlarged drilling for pipe transit.




Fig. 8 - Example 2

LEGEND	Fig. 8
1	Insulating material
2	Inspection plug
3	Chimney inspection entrance
4	Minimum safety distance = 0,5 mt
5	Inclination $\geq 3^\circ$
6	Level section ≤ 1 mt

- Old chimney flue with an inserted pipe of minimum Ø100/120 mm and with an external door which enables the chimney cleaning.




Fig. 9 - Example 3

LEGEND	Fig. 9
1	Insulating material
2	Inspection plug
3	Minimum safety distance = 0,5 mt

- External chimney flue entirely made up of insulated stainless steel pipes, i.e. with double wall of minimum Ø100/120 mm: all must be firmly attached to the wall. For chimney against wind effects please (see **Fig. 5**).
- Ducting system through T-unions which enables an easy cleaning without disassembling the pipes.



We recommend to check with your chimney flue manufacturer the safety distances which must be respected and the type of insulating material. The aforesaid regulations are valid also for holes made on the wall (EN 13501 - EN 13063 - EN 1856 - EN 1806 - EN 15827).

4 COMBUSTION AIR

4.1 EXTERNAL AIR INLET




Fig. 10 - Direct air inflow

LEGEND	Fig. 10
1	Room to ventilate
2	External air inlet

- The room must be endowed with an external air recycling for a good climate in your ambient.
- The air inflow from outside to the inner occurs directly, through an opening on the external wall of the room (see **Fig. 10**).
- Bedrooms, garages, and store of flammable materials are excluded.
- The air inlet should have a total net surface of 80 sqcm²: the aforesaid surface is to widen if inside the room there are other activated appliances (for example: electric ventilators for foul air suction, cooker hoods, other stoves, etc...) which depress the environment.
- At switched on appliance it is necessary to check that the pressure fall between the room and the outside does not exceed 4,0 Pa value: if necessary widen the air inlet (EN 13384).
- The air inlet must be realized at a height close to the floor with an external grid against birds. In such a way it cannot be obstructed by any object.
- **In case of installation with sealed-chamber the air inlet is not necessary.**

4.2 COMBUSTIBLE AIR INLET FOR SEALED-CHAMBER INSTALLATION




Fig. 11 - Air inlet for sealed-chamber installation

LEGEND	Fig. 11
1	$\geq 1,5$ mt
2	$\geq 0,3$ mt
3-3	Sectional view
4	Shield grid
5	Curve inlet to turn downwards

Check if the purchased stove has a sealed-chamber. If the stove is endowed with a sealed-chamber and you want also the whole installation with sealed chamber, please read the following instructions:

- It is necessary to extract the air for combustion directly from outside.
- Use a tube with minimum $\varnothing 60$ mm and maximum 2 meters length; to connect see the back of the stove.
- French standards require installation in double-walled flues (concentric system). The combustion air is drawn from the cavity.
- During installation step is necessary to verify the minimum distances required for the combustible air inlet as (for example) an open door or window causes a vortex which could remove the combustible air necessary to the stove (see the underlying scheme).
- On the external wall it is necessary to install a curve at 90° to protect the combustible air inflow from wind effects: turn the curve inlet downwards, see **Fig. 11**.
- Endow the curve with an external shield grid against birds in such a way that it cannot be obstructed by any object.



Check with your local authorities if exists any restrictive regulation regarding the combustible air inlet: if present, they must be applied



In some countries and/or regions the installation with sealed-chamber is obligatory: in case of doubt, please follow the most restrictive regulations.

4.3 COMBUSTIBLE AIR INLET FOR SEALED-CHAMBER INSTALLATION (KRIS³ - TECNO³ - EVO³ - ELISE³ - SHELL³ - SHELL³ PS - CRISTAL³ - GLASS - VERVE AT - PRETTY AT - TITANIA AT - VENERE AT)

How to connect to the stove in the sealed chamber with concentric system:




Fig. 12 - Phase 1




Fig. 13 - Phase 2




Fig. 14 - Phase 3

- Original position with completely embedded tube (see **Fig. 12**).
- Pull out the tube for 2 cm (see **Fig. 13**).
- Insert the female tube \varnothing 6 cm (see **Fig. 14**).

4.4 COMBUSTIBLE AIR INLET FOR SEALED-CHAMBER INSTALLATION (SHELL³ UP - BREEZE AT)

How to connect to the stove in the sealed chamber with concentric system:



Fig. 15 - Phase 1



Fig. 16 - Phase 2

- Connect the concentric pipe with the fitting located behind the stove (see **Fig. 15**).
- Push the concentric pipe up to stroke end (see **Fig. 16**).

5 INSTALLATION

5.1 INTRODUCTION

- The assembly position must be chosen depending on environment, outlet, chimney flue.
- Check with local authorities if there are any restrictive regulations which regard the combustible air inlet, room ventilation, fume exhaust system together with chimney flue and chimney pot.
- Check if there is the combustible air inlet.
- Check the probable presence of other stoves or appliances which could depress the room.
- Check at switched on stove if there is the presence of CO in the room.
- Check if the chimney has the necessary draught.
- Check if during the fume passage all has been executed in safety (probable fume losses and distances from flammable materials, etc...).
- The installation of the appliance must enable an easy access for appliance, fume exhaust pipes and chimney flue cleaning.
- The installation must enable an easy access to the electric connection plug (see **ELECTRIC CONNECTION a pag. 30**).
- To install more appliances, the external air inlet must be correctly dimensioned (see **FEATURES a pag. 40**).

5.2 OVERALL DIMENSIONS




Fig. 17 - General dimensions: Tecna³

LEGEND	Fig. 17
1	49,1 cm
2	96,1 cm
3	48,8 cm
4	23,8 cm
5	32,5 cm
6	16 cm
7	Exhaust fumes d.8 cm
8	Hole combustion air inlet d.6 cm
9	20 cm




Fig. 18 - General dimensions: Evo³

LEGEND Fig. 18

1	52.8 cm
2	94.1 cm
3	52.8 cm
4	23.8 cm
5	32.5 cm
6	17.3 cm
7	Exhaust fumes d.8 cm
8	Hole combustion air inlet d.6 cm
9	21.5 cm




Fig. 19 - General dimensions: Kriss³

LEGEND Fig. 19

1	52,8 cm
2	94,1 cm
3	52,8 cm
4	23,8 cm
5	32,5 cm
6	17,3 cm
7	Exhaust fumes d.8 cm
8	Hole combustion air inlet d.6 cm
9	21,5 cm




Fig. 20 - General dimensions: Elise³

LEGEND	Fig. 20
1	62 cm
2	100 cm
3	52 cm
4	23,8 cm
5	32,5 cm
6	22,5 cm
7	Exhaust fumes d.8 cm
8	Hole combustion air inlet d.6 cm
9	26,3 cm




Fig. 21 - General dimensions: Shell³

LEGEND Fig. 21

1	55,9 cm
2	100,8 cm
3	55,9 cm
4	19,4 cm
5	32,4 cm
6	21,5 cm
7	Exhaust fumes d.8 cm
8	Hole combustion air inlet d.6 cm
9	45°




Fig. 22 - General dimensions: Glass

LEGEND Fig. 22

1	49,2 cm
2	96,2 cm
3	54,6 cm
4	23,8 cm
5	32,5 cm
6	17,3 cm
7	21,5 cm
8	Hole combustion air inlet d.6 cm
9	Exhaust fumes d.8 cm




Fig. 23 - General dimensions: Verve Airtight

LEGEND	Fig. 23
1	46,6 cm
2	106 cm
3	51,6 cm
4	23,8 cm
5	32,5 cm
6	17,3 cm
7	21,5 cm
8	Hole combustion air inlet d.6 cm
9	Exhaust fumes d.8 cm




Fig. 24 - General dimensions: Cristal^B

LEGEND Fig. 24

1	45,6 cm
2	97 cm
3	50,6 cm
4	20,8 cm
5	32,4 cm
6	13,8 cm
7	Hole combustion air inlet d.6 cm
8	Exhaust fumes d.8 cm
9	17,9 cm




Fig. 25 - General dimensions: Pretty Airtight

LEGEND Fig. 25

1	51 cm
2	97 cm
3	50,7 cm
4	20,8 cm
5	32,4 cm
6	16,9 cm
7	Exhaust fumes d.8 cm
8	Hole combustion air inlet d.6 cm
9	20,9 cm




Fig. 26 - General dimensions: Titania Airtight - Venere Airtight

LEGEND	Fig. 26
1	50 cm
2	97 cm
3	50 cm
4	20,8 cm
5	32,4 cm
6	16,1 cm
7	Exhaust fumes d.8 cm
8	Hole combustion air inlet d.6 cm
9	20,2 cm




Fig. 27 - General dimensions: Shell Ps

LEGEND	Fig. 27
1	52,3 cm
2	114 cm
3	57,5 cm
4	27 cm
5	31,8 cm
6	26,7 cm
7	Exhaust fumes d.8 cm
8	Hole combustion air inlet d.6 cm
9	45°




Fig. 28 - General dimensions: Shelf[®] Up

LEGEND	Fig. 28
1	52,3 cm
2	114 cm
3	60 cm
4	52,2 cm
5	26,1 cm
6	Exhaust fumes d.8 cm
7	Hole combustion air inlet d.6 cm




Fig. 29 - General dimensions: Titania Airtight - Venere Airtight

LEGEND	Fig. 26
1	50 cm
2	97 cm
3	50 cm
4	20,8 cm
5	32,4 cm
6	16,1 cm
7	Exhaust fumes d.8 cm
8	Hole combustion air inlet d.6 cm
9	20,2 cm

5.3 GENERAL INSTALLATION




Fig. 30 - General installation

LEGEND	Fig. 30
1	Stove
2	Minimum lateral distance = 200 mm
3	Minimum rear distance = 200 mm
4	Minimum front distance = 1000 mm

It is obligatory to install the stove away from walls and/or pieces of furniture, with a minimum air flow of 200 mm on the sides and 200 mm on the back, to enable an efficient appliance cooling and a good distribution of heat in the room (see **Fig. 30**).

If the walls are made up of flammable materials, check the safety distances (see **Fig. 30**).

At maximum power check that the wall temperature does not ever exceed 80°C. If it would be necessary please install a fire resistant plate on the concerned walls.

In some countries also masonry load-bearing walls are considered flammable.

5.4 STOVE DOOR REMOVAL/INSTALLATION

DOOR REMOVAL

For some operations (e.g.: side panel assembly and cleaning) you must remove the stove door.

To remove the door:

- Open the door.
- Use a screwdriver to rotate the lever in the direction of the arrow (see **Fig. 31**).
- Lift the door to allow the door pivots to slide out of the structure bracket (see **Fig. 32**).
- Keep the door in a safe place until next use.




Fig. 31 - Remove screws




Fig. 32 - Door removal

DOOR ASSEMBLY

To assemble the door you must centre the pivots fixed to the door, on the structure bracket.

After having mounted the door with the screwdriver, lift the lever so that the door is locked.

5.5 EVO³ SIDE PANELS ASSEMBLY

- Remove the cover: loosen the 4 upper screws (see **Fig. 33**).
- With your finger, fold the upper flaps which are located on the black profiles outwards (see **Fig. 34**).
- Insert the side panels into the corresponding guides letting them slide slowly down to the base (see **Fig. 35**).
- Reposition the cover by centring the special teeth (see **Fig. 36**).




Fig. 33 - Remove screws




Fig. 34 - Fold flaps




Fig. 35 - Insert side panels




Fig. 36 - Position cover

5.6 MOUNTING THE VERVE AIRTIGHT SIDE PANELS

- Remove the front panel: loosen the 4 screws (see **Fig. 37**).
- Hook the coloured panels: fit the front part between the guides on the stove, then hook back through the teeth (see **Fig. 38**).
- Position the front panel (see **Fig. 39**).




Fig. 37 - Remove the front panel




Fig. 38 - Hook the panels




Fig. 39 - Position the front panel

5.7 MOUNTING THE GLASS DOOR

- Tighten the screws on the bushes on the glass: 4 screws with round heads and 2 screws with flat heads (see **Fig. 40**).
- Position the glass on the metal door: hook the screws' heads on the door's holes (see **Fig. 41**).
- Lock the screws (see **Fig. 42**).
- If required, adjust the door from the relative screws on the hinges (see **Fig. 43**).




Fig. 40 - Tighten the screws




Fig. 41 - Position the glass




Fig. 42 - Locking the screws



Fig. 43 - Door adjustment

5.8 MOUNTING THE PRETTY AIRTIGHT SIDE PANELS

METAL

- Place the coloured panel on a surface (see **Fig. 44**) and with the help of clamps, lift all tabs (see **Fig. 45**).
- Hook the panel into the appropriate seats (see **Fig. 46**).
- NB: the 2 opposite tabs are used to lock the panel.



Fig. 44 - Coloured panel



Fig. 45 - Fold tabs



Fig. 46 - Slide the panel on

MAJOLICA AND STONE

- Remove the door (see **STOVE DOOR REMOVAL/INSTALLATION a pag. 22**).
- Loosen the rear and front screws of the side panel (see **Fig. 47**) and remove it (see **Fig. 48**).



Fig. 47 - Remove the screws



Fig. 48 - Removing the side panel

- Place the tiles or the stone facedown on a surface (see **Fig. 49**).
- Position the previously removed panel over the finish at the fixing holes and tighten the screws (see **Fig. 50**).
- Reposition the panel with the finish to the stove.
- Reposition the door.
- NB: the help of a second person when installing the majolica and stone panels is recommended.



Fig. 49 - Finish positioning



Fig. 50 - Tighten the finish to the side

5.9 TECNA³ SIDE PANEL DISASSEMBLY

To access the internal stove parts, disassemble the back side panels as indicated below:

- Loosen the 4 back screws (see **Fig. 51**).
- Unhook the back side panels (see **Fig. 52**).
- To assemble proceed in reverse order.




Fig. 51 - Remove screws




Fig. 52 - Unhook the side panels

To disassemble the front side panels proceed as indicated below:

- Remove the door (see **STOVE DOOR REMOVAL/INSTALLATION a pag. 22**).
- Loosen the 4 screws and remove the black panels above and below the door (see **Fig. 53**).
- Unhook the side panels (see **Fig. 54**).
- To assemble proceed in reverse order.




Fig. 53 - Remove profiles




Fig. 54 - Unhook the side panels

5.10 KRISS³ - CRISTAL³ SIDE PANEL DISASSEMBLY

To access the internal stove parts, disassemble the side panels as indicated below:

- Remove the door (see **STOVE DOOR REMOVAL/INSTALLATION a pag. 22**). (NB: You do not have to disassemble the door to remove the right side panel).
- Loosen the 6 back screws (see **Fig. 55**).
- Loosen the 4 front screws and remove the side panels (see **Fig. 56** and **Fig. 57**).
- To assemble proceed in reverse order.




Fig. 55 - Loosen screws




Fig. 56 - Remove screws




Fig. 57 - Remove side panels

5.11 ELISE³/SHELL³ SIDE PANEL DISASSEMBLY

To access the internal stove parts, disassemble the side panels as indicated below:

- Unhook the side panels from low to high (see **Fig. 58**).
- For assembly, proceed in reverse order, adjusting the front faceplates both vertically and horizontally to bring them level with the side panels (see **Fig. 59** and **Fig. 60**).




Fig. 58 - Remove side panels




Fig. 59 - Locking teeth




Fig. 60 - Adjustments

5.12 VERVE AIRTIGHT SIDE PANEL DISASSEMBLY

To access the internal stove parts, disassemble the side panels as indicated below:

- Loosen the 4 back screws (see **Fig. 69**).
- Remove the side panels (see **Fig. 70**).
- To assemble proceed in reverse order.




Fig. 61 - Loosen screws




Fig. 62 - Remove side panels

5.13 SHELL³ / SHELL³ PS / SHELL³ UP COATING REMOVAL

To access the internal stove parts, disassemble the side panels as indicated below:

- Remove the door and the rh and lh front profiles (see **Fig. 63** and **Fig. 64**).
- Remove the rear screws locking the coques. Remove the upper shell from above and the lower one by pulling it towards you. (see **Fig. 65**, **Fig. 66**, **Fig. 67** and **Fig. 68**).
- For assembly, proceed in reverse order.



Fig. 63 - Door removal



Fig. 64 - Profile screws removal (rh and lh).



Fig. 65 - Front profile removal (rh and lh).



Fig. 66 - Rear screws removal



Fig. 67 - Remove the upper coque from above.



Fig. 68 - Remove the lower coque by pulling it towards you.

5.14 GLASS SIDE PANEL DISASSEMBLY

To access the internal stove parts, disassemble the side panels as indicated below:

- Loosen the 6 back screws (see **Fig. 69**).
- Remove the side panels (see **Fig. 70**).
- To assemble proceed in reverse order.




Fig. 69 - Loosen screws




Fig. 70 - Remove side panels

5.15 BREEZE AIRTIGHT SIDE PANEL DISASSEMBLY

To access the internal stove parts, disassemble the side panels as indicated below:

- Remove the cast iron cover (see **Fig. 71**).
- Loosen the rear screws of the sides (see **Fig. 72**).
- Open the side and release it from the teeth (see **Fig. 73**).
- To assemble proceed in reverse order.




Fig. 71 - Top removal




Fig. 72 - Remove screws




Fig. 73 - Removing the side panel

5.16 ELECTRIC CONNECTION



Warning: the appliance must be installed by an authorized technician!

- The electric connection occurs through a cable with plug put in an electric socket which is able to support charge and tension specific of every model, as described in the technical datas table (see **FEATURES a pag. 40**).
- The plug must be easily accessible when the appliance is installed.

- Please further assure you that your network is endowed with an efficient earth connection: if it does not exist or if it is not efficient, please endow you with one in compliance with the law.
- Connect the supply cable first on the back of the stove (see **Fig. 74**) and then at a wall electric socket.




Fig. 74 - Electric socket with master switch

- The master switch O/I (see **Fig. 74**) is to open only to switch the stove on, otherwise it is advisable to keep it off.
- Do not use extension cables.
- If the feeder cable is damaged, it must be replaced by an authorized technician.
- When the stove is not going to be used for a long period of time, it is advisable to remove the plug from the socket on the wall.

5.17 CONNECTION TO THE EXTERNAL THERMOSTAT

The stove works through a thermostat probe placed in its inner. If you desire, the stove can be connected to an external room thermostat. This operation must be executed by an authorized technician.

Connect the wires from the external thermostat to the "Term opt" terminal on the stove board. Activate the external thermostat (default setting OFF) as indicated below:

- Press the "menu" button.
- Scroll with the arrows to "Settings".
- Select by pressing "menu".
- Scroll with the arrows again to "Ext.Thermostat".
- Select by pressing "menu".
- Press the - + buttons.
- To activate the external thermostat select "on".
- Press the "menu" button to confirm.

5.18 STOVE CALIBRATION AND DEPRESSION MEASUREMENT

This stove has a pickup point positioned on the tank in order to measure the depression of the combustion chamber and verify its proper operation.

To do this, proceed as follows:

- Remove inspection casing "C" from the back of the stove (see **Fig. 75**).
- Loosen nut "D" from the bottom of the tank, near the pressure switch.
- Connect a digital pressure switch with a tube to detect the depression (see **Fig. 76**).
- Load the feed screw via appropriate function.
- Start the stove and set "Fire" at power 1 (the start of this stove lasts from 8 to 10 minutes to ensure minimum draught).
- Compare the read values with those on the table.
- Change power every 10 minutes and wait for it to stabilise.
- Access the user menu and, if necessary, change the parameters.




Fig. 75 - Casing removal




Fig. 76 - Digital pressure switch connection

DATA	P1	P2	P3	P4	P5
Stove depression - temperature 7 kW	19/21 Pa - 110°C	32/35 Pa - 125°C	48/50 Pa - 145°C	52/54 Pa - 160°C	63/65 Pa - 165°C
Stove depression - temperature 8.5 kW	19/21 Pa - 110°C	32/35 Pa - 125°C	49/51 Pa - 155°C	63/65 Pa - 165°C	68/70 Pa - 180°C
Stove depression - temperature 9 kW	19/21 Pa - 110°C	32/35 Pa - 125°C	49/51 Pa - 155°C	63/65 Pa - 165°C	73/75 Pa - 190°C

NB: for good combustion, the depression values must be between + -5 Pa and the temperature values between + - 10°C.

6 SPECIAL MAINTENANCE

6.1 INTRODUCTION

For a long working life of the stove, have a periodic cleaning of the stove as described in the following paragraphs.

- Fume outlet pipes (fume conduit + chimney flue + chimney pot) must always be cleaned, scrubbed and checked by an authorized technician in compliance with local regulations, with the instructions of the manufacturer and those of your insurance company.
- It is also necessary to have the combustion chamber, motors and fans cleaned and to have the gaskets and the electrical elements checked at least once a year.



All these operations must be planned in time with your Authorized Technical Assistance Service.

- After a long ineffective time, before turning on the stove check if there are obstructions in the fume exhaust.
- If the stove had been using continuously and intensely, the whole system (chimney included), must be cleaned and checked more frequently.
- In case of replacement of damaged pieces please ask for the original spare part at the Authorized Retailer.

6.2 FEED SCREW MAINTENANCE

Proceed as follows for the feed screw maintenance:




Fig. 77 - Screw removal




Fig. 78 - Coque removal




Fig. 79 - Gear motor removal

- Enter the tank and loosen the 4 screws of the feed screw coque (see **Fig. 77**).
- Remove the coque (see **Fig. 78**).
- Remove the gear motor by loosening the locking screw (see **Fig. 79**).



Fig. 80 - Spiral removal



Fig. 81 - Bearing removal

- Remove the spiral (see **Fig. 80**).
- If worn, remove the bearing (see **Fig. 81**) and replace it.
- To reassemble, proceed in reverse order.

6.3 FUME CONDUIT CLEANING

The exhaust system must be cleaned every season (or every 1500 operation hours).



Fig. 82 - Fume conduit cleaning

- Remove the inspection lid of the T-union (see **Fig. 82**).
- Extract the ash which has accumulated in the inner.

- After cleaning repeat the operation in reverse order, checking the condition and efficiency of the gasket, and if necessary replace it.



It is important to sealed the cap othrwise noxious fumes will propagate among the room.

6.4 FUME CHAMBER AND FUME PASSAGES CLEANING



Every season (or every 1500 operation hours) the fume chamber and the fume passages cleaning must be executed.

- Remove the side panels of the stove according to the model (see dedicated sections).
- When the stove is cool, remove plate "F" by loosening the two screws (see **Fig. 83**).
- To remove plate "G", you must remove the door (see dedicated section).
- Once the plates have been removed, using the brush provided with the stove, brush the exchanger walls to let dust fall into the lower compartment.
- Remove the upper deflector (see **Fig. 84**), vacuum any ash and clean the internal combustion chamber walls.
- After cleaning, repeat the operation in reverse making sure the gasket is intact and efficient: if necessary, have it replaced by an authorised technician.




Fig. 83 - Plates removal




Fig. 84 - Cleaning

Once the exchanger cleaning has been finished, you must remove the four screws fixing plates "C" to the structure, remove gasket "D" and then clean the lower compartment where all ash deposits from previous cleaning operations have accumulated (see **Fig. 85**). Remove the screws fixing plate "E" to the structure, clean the fan with the brush and vacuum any residue (see **Fig. 86**). If necessary, replace gasket "D".

Check the ceramic fibre gasket seal on the stove door. If necessary, order new gaskets from the dealer for replacement or contact an authorised service centre to perform the entire operation.




Fig. 85 - Plate removal




Fig. 86 - Cleaning



The fume exhaust system cleaning frequency depends on stove use and its installation. We recommend contacting an authorised service centre for the end-of-season cleaning and maintenance operations because the centre will perform an overall check of the parts, as well as the above-mentioned operations.

6.5 LOWER COMPARTMENT CLEANING

Once the combustion chamber cleaning is finished, we recommend cleaning the G grid on the stove back (see **Fig. 87**) and the V fans to remove any dust or dirt, in order to guarantee high performance (see **Fig. 88**).

Every year, clean the room fan to remove ash or dust causing unbalance of the blades and greater noise.




Fig. 87 - Back grid




Fig. 88 - Fans

LEGEND Fig. 87 - Fig. 88

G	Grid
V	Fans



6.6 FUME PIPES ANNUAL CLEANING

Clean once a week from soot with brushes.

The cleaning operation must be executed by a specialized stove-repairer who will provide for the cleaning of fume pipe, chimney flue and chimney pot. He will also check their efficiency and will release a written declaration of the safety of the appliance. This operation must be executed at least once a year.

6.7 GASKET REPLACEMENT

In case of deterioration of fire door, hopper or fume chamber gaskets, it is necessary to replace them by an authorized technician in order to guarantee the good running of the stove.



Use exclusively original spare parts.

7 IN CASE OF ANOMALY






7.1 PROBLEM SOLVING



























Before of every Authorized Technician intervention, the same Technician has the duty to check if the parameters of the mother board correspond to those of the table you own.




In case of doubts regarding the use of the stove, please contact ALWAYS the Authorized Technician on order to avoid irreparable damages!

PROBLEM	CAUSE	SOLUTION	INTERVENTION
The control display does not switch on	The stove is without power supply	Check if the plug is connected.	
	Burned protection fuse in the electric socket	Replace the protection fuses in the electric socket (3.15A-250V).	
	Faulty control display	Replace the control display.	
	Faulty flat cable	Replace the flat cable.	
	Faulty electronic board	Replace the mother board.	

PROBLEM	CAUSE	SOLUTION	INTERVENTION
Pellets do not reach the combustion chamber	Empty hopper	Full the hopper.	
	Open fire door or open pellet door	Close fire door and pellet door and check that there are no pellet grains at the gasket level.	
	Clogged stove	Fume chamber cleaning	
	Auger blocked by a foreign object (for example nails)	Clean the auger.	
	The auger geared motor is out of order	Replace the geared motor.	
	Check if on the display there is an "ACTIVE ALARM"	Have the stove checked.	
The fire extinguish and the stove stops	Empty hopper	Full the hopper.	
	Auger blocked by a foreign object (for example nails)	Clean the auger.	
	Bad quality pellets	Try other types of pellets.	
	Pellet drop value too low "phase 1"	Adjust the pellet loading.	
	Check if on the display there is an "ACTIVE ALARM"	Have the stove checked.	

PROBLEM	CAUSE	SOLUTION	INTERVENTION
Flames are weak and orange coloured, pellets do not burn properly and the glass blackens	Not sufficient combustion air	Check as following: probable obstructions of the combustible air inlet from the back or from the bottom of the stove; burning pot obstructed holes with too ash remains. Have the fan blades and auger cleaned.	
	Obstructed exhaust	The exhaust chimney is partially or totally obstructed. Contact an expert stove-repairer who checks the stove from the exhaust up to the chimney pot. Provide immediately for stove cleaning.	
	Obstructed stove	Provide immediately at the inner cleaning of the stove.	
	The fume fan is out of order	The pellets can burn also thanks to chimney flue depression without the aid of the fume fan. Have the fume fan immediately replaced. It can be noxious to health to let the stove running without fume fan.	
The exchanger fan continues to turn even though the stove has just cooled	Faulty fume temperature probe	Replace the fume probe.	
	Faulty mother board	Replace the mother board.	
Ash remains along the stove	Faulty or out of order door gaskets	Replace the gaskets.	
	Not sealed fume pipes	Contact an expert stove-repairer who will immediately provide for sealing the junctions with high-temperature silicone and/or for replacing pipes with those in compliance to current regulations. A not sealed fume channelisation can be noxious to health.	
The stove is at its highest power but does not heat up.	Ambient temperature reached.	The stove is at its minimum value. Increase the desired ambient temperature.	
Stove running and display showing "Smoke Overtemperature"	Reached fume outlet limit temperature	The stove runs at minimum. NO PROBLEM!	
The stove's smoke duct produces condensation	Low smoke temperature	Check that the flue is not clogged.	
		Increase stove power to minimum (pellet drop and fan revs).	
		Install condensation collection cup.	

PROBLEM	CAUSE	SOLUTION	INTERVENTION
Stove running and display showing "SERVICE"	Routine maintenance alert (it does not block the system)	When this flashing message appears upon start-up, it means that the preset operating hours have elapsed before maintenance. Contact the service centre.	

8 TECHNICAL DATAS

8.1 FUSE REPLACEMENT

For fuse replacement in the electric socket which stands on the back of the stove, extract the fuses to change with the aid of a screwdriver for opening the shutter (see **Fig. 89**).




Fig. 89 - Shutter with fuses to remove

8.2 FEATURES

DESCRIPTION	KRISS ³ - 7 kW	EVO ³ - 7 kW	CRISTAL ³ - 8,5 kW
WIDTH	52,8 cm	51,5 cm	45,5 cm
DEPTH	52,8 cm	48,5 cm	51 cm
HEIGHT	94,1 cm	94,5 cm	97 cm
WEIGHT	88 kg	81 - 90,5 - 126 kg	79 kg
INTRODUCED THERMIC POWER (Min/Max)	2,58 - 7,96 kW	2,58 - 7,96 kW	2,58 - 9,73 kW
NOMINAL THERMIC POWER (Min/Max)	2,4 - 7,15 kW	2,4 - 7,15 kW	2,4 - 8,67 kW
EFICIENCY (Min/Max)	92,91 - 89,8 %	92,91 - 89,8 %	92,91 - 89,14 %
FUME TEMPERATURE (Min/Max)	95,3 - 171,5 °C	95,3 - 171,5 °C	95,3 - 196,6 °C
FUME MAXIMUM LOADING CAPACITY (Min/Max)	2,2 - 4,4 g/s	2,2 - 4,4 g/s	2,2 - 4,8 g/s
CO EMISSIONS (13% O ₂) (Min/Max)	0,022 - 0,004 %	0,022 - 0,004 %	0,022 - 0,006 %
OGC EMISSIONS (13% O ₂) (Min/Max)	3,9 - 0,3 mg/Nm ³	3,9 - 0,3 mg/Nm ³	3,9 - 1,5 mg/Nm ³
NO _x EMISSIONS (13% O ₂) (Min/Max)	104,4 - 134,4 mg/Nm ³	104,4 - 134,4 mg/Nm ³	104,4 - 135,7 mg/Nm ³
Medium CO CONTENTS at 13% O ₂ (Min/Max)	274 - 44 mg/Nm ³	274 - 44 mg/Nm ³	274 - 79 mg/Nm ³
Medium POWDER CONTENTS at 13% O ₂ (Min/Max)	19,3 - 13,4 mg/Nm ³	19,3 - 13,4 mg/Nm ³	19,3 - 14 mg/Nm ³
CHIMNEY DEPRESSION (Min/Max)	7,7 - 11,5 Pa	7,7 - 11,5 Pa	7,7 - 11,6 Pa
ON SHARED CHIMNEY FLUE	NO	NO	NO
FUME OUTLET DIAMETER	Ø80 mm	Ø80 mm	Ø80 mm
COMBUSTIBLE	Pellet Ø6-7 mm	Pellet Ø6-7 mm	Pellet Ø6-7 mm
PELLETS HEATING VALUE	5 kWh/kg	5 kWh/kg	5 kWh/kg
PELLETS HUMIDITY	≤ 10%	≤ 10%	≤ 10%
HEATING VOL. 18/20°C Coeff. 0,045 kW (Min/Max)	58 - 172 m ³	58 - 172 m ³	58 - 208 m ³
HOURLY CONSUMPTION (Min/Max)	0,53 - 1,65 kg/h	0,53 - 1,65 kg/h	0,53 - 2,01 kg/h
HOPPER CAPACITY	18 kg	18 kg	18 kg
RANGE (Min/Max)	34 - 10,9 h	34 - 10,9 h	34 - 9 h
SUPPLY	230 V - 50 Hz	230 V - 50 Hz	230 V - 50 Hz
POWER INPUT (Max)	364 W	364 W	346 kW
IGNITER RESISTANCE POWER INPUT	300 W	300 W	300 W
MINIMUM EXTERNAL AIR INLET (last effective area)	80 cm ²	80 cm ²	80 cm ²
STOVE WITH SEALED CHAMBER	YES	YES	YES
EXTERNAL AIR INLET FOR SEALED CHAMBER	60 mm	60 mm	60 mm
DISTANCE FROM COMBUSTIBLE MATERIAL (back/side/bottom)	200 / 200 / 0 mm	200 / 200 / 0 mm	200 / 200 / 0 mm
DISTANCE FROM COMBUSTIBLE MATERIAL (ceiling/front)	0 / 1000 mm	0 / 1000 mm	0 / 1000 mm

DESCRIPTION	KRISS ³ - 8,5 kW	EVO ³ - 8,5 kW	TECNA ³ - 8,5 kW
WIDTH	52,8 cm	51,5 cm	49,1 cm
DEPTH	52,8 cm	48,5 cm	48,8 cm
HEIGHT	94,1 cm	94,5 cm	96,1 cm
WEIGHT	88 kg	81 - 92 - 126 kg	89 kg
INTRODUCED THERMIC POWER (Min/Max)	2,58 - 9,73 kW	2,58 - 9,73 kW	2,58 - 9,73 kW
NOMINAL THERMIC POWER (Min/Max)	2,4 - 8,67 kW	2,4 - 8,67 kW	2,4 - 8,67 kW
EFICIENCY (Min/Max)	92,91 - 89,14 %	92,91 - 89,14 %	92,91 - 89,14 %
FUME TEMPERATURE (Min/Max)	95,3 - 196,6 °C	95,3 - 196,6 °C	95,3 - 196,6 °C
FUME MAXIMUM LOADING CAPACITY (Min/Max)	2,2 - 4,8 g/s	2,2 - 4,8 g/s	2,2 - 4,8 g/s
CO EMISSIONS (13% O ₂) (Min/Max)	0,022 - 0,006 %	0,022 - 0,006 %	0,022 - 0,006 %
OGC EMISSIONS (13% O ₂) (Min/Max)	3,9 - 1,5 mg/Nm ³	3,9 - 1,5 mg/Nm ³	3,9 - 1,5 mg/Nm ³
NO _x EMISSIONS (13% O ₂) (Min/Max)	104,4 - 135,7 mg/Nm ³	104,4 - 135,7 mg/Nm ³	104,4 - 135,7 mg/Nm ³
Medium CO CONTENTS at 13% O ₂ (Min/Max)	274 - 79 mg/Nm ³	274 - 79 mg/Nm ³	274 - 79 mg/Nm ³
Medium POWDER CONTENTS at 13% O ₂ (Min/Max)	19,3 - 14 mg/Nm ³	19,3 - 14 mg/Nm ³	19,3 - 14 mg/Nm ³
CHIMNEY DEPRESSION (Min/Max)	7,7 - 11,6 Pa	7,7 - 11,6 Pa	7,7 - 11,6 Pa
ON SHARED CHIMNEY FLUE	NO	NO	NO
FUME OUTLET DIAMETER	Ø80 mm	Ø80 mm	Ø80 mm
COMBUSTIBLE	Pellet Ø6-7 mm	Pellet Ø6-7 mm	Pellet Ø6-7 mm
PELLETS HEATING VALUE	5 kWh/kg	5 kWh/kg	5 kWh/kg
PELLETS HUMIDITY	≤ 10%	≤ 10%	≤ 10%
HEATING VOLUME 18/20°C Coeff. 0,045 kW (Min/Max)	58 - 208 m ³	58 - 208 m ³	58 - 208 m ³
HOURLY CONSUMPTION (Min/Max)	0,53 - 2,01 kg/h	0,53 - 2,01 kg/h	0,53 - 2,01 kg/h
HOPPER CAPACITY	18 kg	18 kg	18 kg
RANGE (Min/Max)	34 - 9 h	34 - 9 h	34 - 9 h
SUPPLY	230 V - 50 Hz	230 V - 50 Hz	230 V - 50 Hz
POWER INPUT (Max)	346 kW	346 kW	346 kW
IGNITER RESISTANCE POWER INPUT	300 W	300 W	300 W
MINIMUM EXTERNAL AIR INLET (last effective area)	80 cm ²	80 cm ²	80 cm ²
STOVE WITH SEALED CHAMBER	YES	YES	YES
EXTERNAL AIR INLET FOR SEALED CHAMBER	60 mm	60 mm	60 mm
DISTANCE FROM COMBUSTIBLE MATERIAL (back/side/bottom)	200 / 200 / 0 mm	200 / 200 / 0 mm	200 / 200 / 0 mm
DISTANCE FROM COMBUSTIBLE MATERIAL (ceiling/front)	0 / 1000 mm	0 / 1000 mm	0 / 1000 mm

DESCRIPTION	ELISE ³ - 8,5 kW	SHELL ³ - 8,5 kW	KRISS ³ - 9 kW
WIDTH	62 cm	53,4 cm	52,8 cm
DEPTH	52 cm	52,2 cm	52,8 cm
HEIGHT	100 cm	99,5 cm	94,1 cm
WEIGHT	95 kg	88 kg	88 kg
INTRODUCED THERMIC POWER (Min/Max)	2,58 - 9,73 kW	2,58 - 9,73 kW	2,58 - 10,25 kW
NOMINAL THERMIC POWER (Min/Max)	2,4 - 8,67 kW	2,4 - 8,67 kW	2,4 - 9,1 kW
EFICIENCY (Min/Max)	92,91 - 89,14 %	92,91 - 89,14 %	92,91 - 88,79 %
FUME TEMPERATURE (Min/Max)	95,3 - 196,6 °C	95,3 - 196,6 °C	95,3 - 204,6 °C
FUME MAX LOADING CAPACITY (Min/Max)	2,2 - 4,8 g/s	2,2 - 4,8 g/s	2,2 - 5 g/s
CO EMISSIONS (13% O ₂) (Min/Max)	0,022 - 0,006 %	0,022 - 0,006 %	0,022 - 0,005 %
OGC EMISSIONS (13% O ₂) (Min/Max)	3,9 - 1,5 mg/Nm ³	3,9 - 1,5 mg/Nm ³	3,9 - 2,1 mg/Nm ³
NO _x EMISSIONS (13% O ₂) (Min/Max)	104,4 - 135,7 mg/Nm ³	104,4 - 135,7 mg/Nm ³	104,4 - 138,7 mg/Nm ³
Medium CO CONTENTS at 13% O ₂ (Min/Max)	274 - 79 mg/Nm ³	274 - 79 mg/Nm ³	274 - 63 mg/Nm ³
Medium POWDER CONTENTS at 13% O ₂ (Min/Max)	19,3 - 14 mg/Nm ³	19,3 - 14 mg/Nm ³	19,3 - 12,1 mg/Nm ³
CHIMNEY DEPRESSION (Min/Max)	7,7 - 11,6 Pa	7,7 - 11,6 Pa	7,7 - 11,7 Pa
ON SHARED CHIMNEY FLUE	NO	NO	NO
FUME OUTLET DIAMETER	Ø80 mm	Ø80 mm	Ø80 mm
COMBUSTIBLE	Pellet Ø6-7 mm	Pellet Ø6-7 mm	Pellet Ø6-7 mm
PELLETS HEATING VALUE	5 kWh/kg	5 kWh/kg	5 kWh/kg
PELLETS HUMIDITY	≤ 10%	≤ 10%	≤ 10%
HEATING VOLUME 18/20°C Coeff. 0,045 kW (Min/Max)	58 - 208 m ³	58 - 208 m ³	58 - 218 m ³
HOURLY CONSUMPTION (Min/Max)	0,53 - 2,01 kg/h	0,53 - 2,01 kg/h	0,53 - 2,12 kg/h
HOPPER CAPACITY	18 kg	18 kg	18 kg
RANGE (Min/Max)	34 - 9 h	34 - 9 h	34 - 8,5 h
SUPPLY	230 V - 50 Hz	230 V - 50 Hz	230 V - 50 Hz
POWER INPUT (Max)	346 kW	346 kW	346 kW
IGNITER RESISTANCE POWER INPUT	300 W	300 W	300 W
MINIMUM EXTERNAL AIR INLET (last effective area)	80 cm ²	80 cm ²	80 cm ²
STOVE WITH SEALED CHAMBER	YES	YES	YES
EXTERNAL AIR INLET FOR SEALED CHAMBER	60 mm	60 mm	60 mm
DISTANCE FROM COMBUSTIBLE MATERIAL (back/side/bottom)	200 / 200 / 0 mm	200 / 200 / 0 mm	200 / 200 / 0 mm
DISTANCE FROM COMBUSTIBLE MATERIAL (ceiling/front)	0 / 1000 mm	0 / 1000 mm	0 / 1000 mm

DESCRIPTION	VERVE AIRTIGHT - 8,5 kW	GLASS - 8,5 kW	PRETTY AIRTIGHT - 8,5 kW
WIDTH	46,6 cm	49,2 cm	52 cm
DEPTH	51,6 cm	54,6 cm	51 cm
HEIGHT	106 cm	96,2 cm	97 cm
WEIGHT	79 - 93,7 kg	90 kg	82 - 90,8 - 118 kg
INTRODUCED THERMIC POWER (Min/Max)	2,58 - 9,73 kW	2,58 - 9,73 kW	2,58 - 9,73 kW
NOMINAL THERMIC POWER (Min/Max)	2,4 - 8,67 kW	2,4 - 8,67 kW	2,4 - 8,67 kW
EFFICIENCY (Min/Max)	92,91 - 89,14 %	92,91 - 89,14 %	92,91 - 89,14 %
FUME TEMPERATURE (Min/Max)	95,3 - 196,6 °C	95,3 - 196,6 °C	95,3 - 196,6 °C
FUME MAXIMUM LOADING CAPACITY (Min/Max)	2,2 - 4,8 g/s	2,2 - 4,8 g/s	2,2 - 4,8 g/s
CO EMISSIONS (13% O ₂) (Min/Max)	0,022 - 0,006 %	0,022 - 0,006 %	0,022 - 0,006 %
OGC EMISSIONS (13% O ₂) (Min/Max)	3,9 - 1,5 mg/Nm ³	3,9 - 1,5 mg/Nm ³	3,9 - 1,5 mg/Nm ³
NO _x EMISSIONS (13% O ₂) (Min/Max)	104,4 - 135,7 mg/Nm ³	104,4 - 135,7 mg/Nm ³	104,4 - 135,7 mg/Nm ³
Medium CO CONTENTS at 13% O ₂ (Min/Max)	274 - 79 mg/Nm ³	274 - 79 mg/Nm ³	274 - 79 mg/Nm ³
Medium POWDER CONTENTS at 13% O ₂ (Min/Max)	19,3 - 14 mg/Nm ³	19,3 - 14 mg/Nm ³	19,3 - 14 mg/Nm ³
CHIMNEY DEPRESSION (Min/Max)	7,7 - 11,6 Pa	7,7 - 11,6 Pa	7,7 - 11,6 Pa
ON SHARED CHIMNEY FLUE	NO	NO	NO
FUME OUTLET DIAMETER	Ø80 mm	Ø80 mm	Ø80 mm
COMBUSTIBLE	Pellet Ø6-7 mm	Pellet Ø6-7 mm	Pellet Ø6-7 mm
PELLETS HEATING VALUE	5 kWh/kg	5 kWh/kg	5 kWh/kg
PELLETS HUMIDITY	≤ 10%	≤ 10%	≤ 10%
HEATING VOLUME 18/20°C Coeff. 0,045 kW (Min/Max)	58 - 208 m ³	58 - 208 m ³	58 - 208 m ³
HOURLY CONSUMPTION (Min/Max)	0,53 - 2,01 kg/h	0,53 - 2,01 kg/h	0,53 - 2,01 kg/h
HOPPER CAPACITY	18 kg	18 kg	18 kg
RANGE (Min/Max)	34 - 9 h	34 - 9 h	34 - 9 h
SUPPLY	230 V - 50 Hz	230 V - 50 Hz	230 V - 50 Hz
POWER INPUT (Max)	346 kW	346 kW	346 kW
IGNITER RESISTANCE POWER INPUT	300 W	300 W	300 W
MINIMUM EXTERNAL AIR INLET (last effective area)	80 cm ²	80 cm ²	80 cm ²
STOVE WITH SEALED CHAMBER	YES	YES	YES
EXTERNAL AIR INLET FOR SEALED CHAMBER	60 mm	60 mm	60 mm
DISTANCE FROM COMBUSTIBLE MATERIAL (back/side/bottom)	200 / 200 / 0 mm	200 / 200 / 0 mm	200 / 200 / 0 mm
DISTANCE FROM COMBUSTIBLE MATERIAL (ceiling/front)	0 / 1000 mm	0 / 1000 mm	0 / 1000 mm

DESCRIPTION	TITANIA AIRTIGHT - 8,5 kW	VENERE AIRTIGHT - 8,5 kW	SHELL3 PS - 9 kW
WIDTH	50 cm	50 cm	52,3 cm
DEPTH	97 cm	97 cm	57,5 cm
HEIGHT	50 cm	50 cm	114 cm
WEIGHT	79 kg	79 kg	85,3 kg
INTRODUCED THERMIC POWER (Min/Max)	2,58 - 9,73 kW	2,58 - 9,73 kW	2,58 - 10,25 kW
NOMINAL THERMIC POWER (Min/Max)	2,4 - 8,67 kW	2,4 - 8,67 kW	2,4 - 9,1 kW
EFFICIENCY (Min/Max)	92,91 - 89,14 %	92,91 - 89,14 %	92,91 - 88,79 %
FUME TEMPERATURE (Min/Max)	95,3 - 196,6 °C	95,3 - 196,6 °C	95,3 - 204,6 °C
FUME MAXIMUM LOADING CAPACITY (Min/Max)	2,2 - 4,8 g/s	2,2 - 4,8 g/s	2,2 - 5 g/s
CO EMISSIONS (13% O ₂) (Min/Max)	0,022 - 0,006 %	0,022 - 0,006 %	0,022 - 0,005 %
OGC EMISSIONS (13% O ₂) (Min/Max)	3,9 - 1,5 mg/Nm ³	3,9 - 1,5 mg/Nm ³	3,9 - 2,1 mg/Nm ³
NO _x EMISSIONS (13% O ₂) (Min/Max)	104,4 - 135,7 mg/Nm ³	104,4 - 135,7 mg/Nm ³	104,4 - 138,7 mg/Nm ³
Medium CO CONTENTS at 13% O ₂ (Min/Max)	274 - 79 mg/Nm ³	274 - 79 mg/Nm ³	274 - 63 mg/Nm ³
Medium POWDER CONTENTS at 13% O ₂ (Min/Max)	19,3 - 14 mg/Nm ³	19,3 - 14 mg/Nm ³	19,3 - 12,1 mg/Nm ³
CHIMNEY DEPRESSION (Min/Max)	7,7 - 11,6 Pa	7,7 - 11,6 Pa	7,7 - 11,7 Pa
ON SHARED CHIMNEY FLUE	NO	NO	NO
FUME OUTLET DIAMETER	Ø80 mm	Ø80 mm	Ø80 mm
COMBUSTIBLE	Pellet Ø6-7 mm	Pellet Ø6-7 mm	Pellet Ø6-7 mm
PELLETS HEATING VALUE	5 kWh/kg	5 kWh/kg	5 kWh/kg
PELLETS HUMIDITY	≤ 10%	≤ 10%	≤ 10%
HEATING VOLUME 18/20°C Coeff. 0,045 kW (Min/Max)	58 - 208 m ³	58 - 208 m ³	58 - 218 m ³
HOURLY CONSUMPTION (Min/Max)	0,53 - 2,01 kg/h	0,53 - 2,01 kg/h	0,53 - 2,12 kg/h
HOPPER CAPACITY	18 kg	18 kg	18 kg
RANGE (Min/Max)	34 - 9 h	34 - 9 h	34 - 8,5 h
SUPPLY	230 V - 50 Hz	230 V - 50 Hz	230 V - 50 Hz
POWER INPUT (Max)	346 kW	346 kW	346 kW
IGNITER RESISTANCE POWER INPUT	300 W	300 W	300 W
MINIMUM EXTERNAL AIR INLET (last effective area)	80 cm ²	80 cm ²	80 cm ²
STOVE WITH SEALED CHAMBER	YES	YES	YES
EXTERNAL AIR INLET FOR SEALED CHAMBER	60 mm	60 mm	60 mm
DISTANCE FROM COMBUSTIBLE MATERIAL (back/side/bottom)	200 / 200 / 0 mm	200 / 200 / 0 mm	200 / 200 / 0 mm
DISTANCE FROM COMBUSTIBLE MATERIAL (ceiling/front)	0 / 1000 mm	0 / 1000 mm	0 / 1000 mm

DESCRIPTION	SHELL3 UP - 9 kW	BREEZE AIRTIGHT - 9 kW	
WIDTH	52,3 cm	52,8 cm	
DEPTH	57,5 cm	60 cm	
HEIGHT	114 cm	114 cm	
WEIGHT	88 kg	88 kg	
INTRODUCED THERMIC POWER (Min/Max)	2,58 - 10,25 kW	2,58 - 10,25 kW	
NOMINAL THERMIC POWER (Min/Max)	2,4 - 9,1 kW	2,4 - 9,1 kW	
EFFICIENCY (Min/Max)	92,91 - 88,79 %	92,91 - 88,79 %	
FUME TEMPERATURE (Min/Max)	95,3 - 204,6 °C	95,3 - 204,6 °C	
FUME MAXIMUM LOADING CAPACITY (Min/Max)	2,2 - 5 g/s	2,2 - 5 g/s	
CO EMISSIONS (13% O ₂) (Min/Max)	0,022 - 0,005 %	0,022 - 0,005 %	
OGC EMISSIONS (13% O ₂) (Min/Max)	3,9 - 2,1 mg/Nm ³	3,9 - 2,1 mg/Nm ³	
NO _x EMISSIONS (13% O ₂) (Min/Max)	104,4 - 138,7 mg/Nm ³	104,4 - 138,7 mg/Nm ³	
Medium CO CONTENTS at 13% O ₂ (Min/Max)	274 - 63 mg/Nm ³	274 - 63 mg/Nm ³	
Medium POWDER CONTENTS at 13% O ₂ (Min/Max)	19,3 - 12,1 mg/Nm ³	19,3 - 12,1 mg/Nm ³	
CHIMNEY DEPRESSION (Min/Max)	7,7 - 11,7 Pa	7,7 - 11,7 Pa	
ON SHARED CHIMNEY FLUE	NO	NO	
FUME OUTLET DIAMETER	Ø80 mm	Ø80 mm	
COMBUSTIBLE	Pellet Ø6-7 mm	Pellet Ø6-7 mm	
PELLETS HEATING VALUE	5 kWh/kg	5 kWh/kg	
PELLETS HUMIDITY	≤ 10%	≤ 10%	
HEATING VOLUME 18/20°C Coeff. 0,045 kW (Min/Max)	58 - 218 m ³	58 - 218 m ³	
HOURLY CONSUMPTION (Min/Max)	0,53 - 2,12 kg/h	0,53 - 2,12 kg/h	
HOPPER CAPACITY	18 kg	18 kg	
RANGE (Min/Max)	34 - 8,5 h	34 - 8,5 h	
SUPPLY	230 V - 50 Hz	230 V - 50 Hz	
POWER INPUT (Max)	346 kW	346 kW	
IGNITER RESISTANCE POWER INPUT	300 W	300 W	
MINIMUM EXTERNAL AIR INLET (last effective area)	80 cm ²	80 cm ²	
STOVE WITH SEALED CHAMBER	YES	YES	
EXTERNAL AIR INLET FOR SEALED CHAMBER	60 mm	60 mm	
DISTANCE FROM COMBUSTIBLE MATERIAL (back/side/bottom)	200 / 200 / 0 mm	200 / 200 / 0 mm	
DISTANCE FROM COMBUSTIBLE MATERIAL (ceiling/front)	0 / 1000 mm	0 / 1000 mm	

NOTE

[illegible]



89018106B

Rev. 01 - 2018

CADEL srl
31025 S. Lucia di Piave - TV
Via Foresto sud, 7 - Italy
Tel. +39.0438.738669
Fax +39.0438.73343

www.cadelsrl.com
www.free-point.it